

Calibre 2230

Ø20.00mm
Ht: 5.40mm
Train: 28.800

- Automatic
- Centre Seconds
- Shock Proof
- 31 Jewels

Base Calibre 2230













Image	Rolex No.	Description
	137	Bridle
	167	Screw for bridle
	4493	Cap-jewel for balance-upper / lower
	4494	Spring for in setting for escape wheel and balance-upper /lower
	96041	Jewel for: <ul style="list-style-type: none"> • second wheel-upper • third wheel-upper /lower
	2130-419	Pallet staff
	2130-425	Roller
	2130-5100	Screw for case (without ring)
	2130-9330	Jewel for: <ul style="list-style-type: none"> • driving wheel for ratchet wheel-upper • reversing wheel-upper /lower • oscillating weight-lower
	2130-0913	In setting for escape wheel-upper /lower
	2130-0913-2	Cap jewel for escape wheel-upper /lower
	2130-0915-1	In setting for balance-upper /lower












Image	Rolex No.	Description
	2130-0916	Shock-absorber for balance-lower
	2230-100	Main plate
	2230-105	Barrel bridge
	2230-110	Train wheel bridge
	2230-115	Pallet bridge
	2230-120	Balance bridge
	2230-125	Minute pinion bridge
	2230-135	Bridge for automatic device, lower
	2230-140	Bridge for automatic device, upper
	2230-142-1	Automatic device module Ø 19.65mm
	2230-142-2	Automatic device module Ø 22.20mm
	2230-201	Winding stem
	2230-201-1	Winding stem with banking




















Image	Rolex No.	Description
	2230-204	Winding pinion
	2230-205	Sliding pinion
	2230-209	Crown wheel seating
	2230-210	Crown wheel
	2230-211	Crown wheel core
	2230-213	Intermediate crown wheel
	2230-217	Yoke for sliding gear
	2230-220	Setting lever
	2230-225	Spring for setting lever
	2230-231	Jumper for setting lever
	2230-239	Yoke for sliding pinion
	2230-241	Spring for yoke
	2230-245	Spring for balance stop
	2230-246	Bridle for balance stop spring
	2230-249	Setting wheel core
	2230-250	Setting wheel
	2230-260	Minute wheel
	2230-270	Cannon pinion ht. 1.84mm
	2230-270-1	Cannon pinion ht. 1.54mm
	2230-281	Hour wheel ht. 1.07mm
	2230-281-1	Hour wheel ht. 0.78mm



















Image	Rolex No.	Description
	2230-300	Click
	2230-301	Spring for click
	2230-305	Ratchet wheel
	2230-307	Barrel arbor
	2230-310	Barrel with arbor
	2230-311	Mainspring, strength standard
 	2230-330	Great wheel
	2230-335	Minute pinion with cannon pinion ht. 1.84mm
	2230-335-1	Minute pinion with cannon pinion ht. 1.54mm
 	2230-340	Third wheel
 	2230-360	Second wheel
 	2230-410	Escape wheel
	2230-421	Pallet fork
	2230-429	Balance staff
	2230-432	Balance with Breguet hairspring, timed

Image	Rolex No.	Description
	2230-450	Stud support
	2230-451	Bridle for stud support
	2230-475	Driving pinion for balance bridge height adjustment
	2230-478	Bridle for balance bridge height adjustment
 	2230-510	Driving wheel for ratchet wheel
 	2230-540	Reversing wheel, mounted
	2230-550	Pinion for oscillating weight
	2230-560-1	Spring-clip for oscillating weight: • ht. 0.150mm
	2230-560-2	• ht. 0.135mm
	2230-560-3	• ht. 0.165mm
	2230-561	Bridle for spring-clip
	2230-568	Axle for oscillating weight
	2230-570-1	Oscillating weight Ø 19.65mm
	2230-570-2	Oscillating weight Ø 22.20mm
	2230-975	Enlargement ring
	2230-5000	Set of screws

























Image	Rolex No.	Description
	2230-5013	Screw for dial
	2230-5110	Screw for: <ul style="list-style-type: none"> • barrel bridge • train wheel bridge • balance bridge • automatic device bridge • automatic device module
	2230-5115	Screw for: <ul style="list-style-type: none"> • pallet bridge • minute pinion bridge • setting lever spring • setting lever jumper • bridle for balance stop spring • bridle for stud holder • bridle for height adjustment balance bridge
	2230-5120	Regulating nut for balance bridge height adjustment
	2230-5210	Screw for crown wheel
	2230-5300	Screw for: <ul style="list-style-type: none"> • click • yoke for sliding gear
	2230-5305	Screw for ratchet wheel
	2230-5450	Screw for hairspring bridle
	2230-5561	Screw for bridle of spring clip
	2230-5975	Screw for enlargement ring
	2230-7120	Tapped foot for balance bridge
	2230-7121	Tapped foot for regulating balance bridge
	2230-7260	Stud for minute wheel

Image	Rolex No.	Description
	2230-9310	Jewel for barrel-upper
	2230-9311	Jewel for barrel-lower
	2230-9331	Jewel for great wheel-upper / lower
	2230-9360	Jewel for second wheel-lower
	2230-9361	Jewel for second wheel support-lower
	2230-9421	Jewel for pallet fork-upper /lower
	2230-9510	Jewel for driving wheel of the ratchet wheel-lower
	2230-9511	Jewel for driving wheel for ratchet wheel support
	2230-9570	Jewel for oscillating weight-upper
	2230-0915	Shock-absorber for balance-upper
	2230-0945	Friction spring for hour wheel